

Mini Lock Fitting Instructions

N.B The exact hitch model may vary from the illustration, however the fitting procedure remains the same.



1. Insert the dummy ring plate or ball.

Note: If the hitch handle is in the raised position the plate can be used to release the handle.



2. Offer up the bottom channel.

Note: for AKS1300 a cut out is provided to fit around red handle.



3. Place the top box over the bottom channel.



4. Lower the top box into position until both sets of holes line up.



5. With the lock bolt in the unlocked position push it through the holes.



6. Push the cup over the end of the lock bolt and turn the key 1/4 turn clockwise to lock it into position. Remove the key.

For further guidance view our fitting video at www.bulldogsecure.com

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.
Tel: 01952 728171
Email sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.