

Mini Lock Fitting Instructions

N.B Exact hitch model may vary from illustration, however fitting procedure remains the same.

Warning: . When fitting Minilock to ALKO Hitch Stabilisers, the handle (1) must be raised, then rested back against red plastic cover once Mini Lock is fitted.



AKS 2000
AKS 2500
AKS 2004
AKS 3004



1. Insert dummy ring plate. If hitch handle is in raised position the plate can be used to release handle.



2. Offer up bottom channel. (Note for AKS1300 a cut out is provided to fit around red handle)



3. Place powder coated top box over bottom channel.



4. And lower until holes in both line up.



5. Insert locking bolt.



6. Push cup over end of locking bolt. turn key quarter turn clockwise to lock and remove key. Fit red plastic cover.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.
Tel: 01952 728171 Fax: 01952 728117
Email sales@bulldogsecure.com www.bulldogsecure.com
ML58-5

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.