


WW100B Fitting Instructions



IMPORTANT READ FIRST: In order to fit WW100B Hitchlock the front fixing bolt M12 x 100 (enclosed in this package) needs to be used in place of the standard M12 x 90. A 9mm long bush should be fitted either side of the coupling head. Do not use any other washers on this bolt. Ensure thread protrudes beyond self locking nut. Refer to WS3000 assembly and operating instructions for details of rear bolt assembly.

Tightening torque of fixing bolts M12, 10.9: WS3000-D - 90Nm
WS3000-H - 70Nm.

N.B You may find it helpful to have everything close at hand and the lock bolt in the unlocked position separated from the cup, because the hitch lock needs to be held in place with one hand.

Illustration of front horizontal bolt.



1. Lower the hitch handle by inserting the dummy ball into the hitch and pushing firmly upwards.



2. Pass up hitch lock from beneath the coupling head ensuring front fixing bolt fits inside.

Note: A cut out is provided where a rear vertical bolt fixing is used.



3. Place steel shield plate over the handle.



4. Insert the locking bolt through the two holes in the hitch lock and push Cup over end of locking bolt. Turn key ¼ turn clockwise to lock and remove the key.

To Unlock: Insert key, rotate ¼ turn anti-clockwise and remove cap.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.

Tel: 01952 728171

Email sales@bulldogsecure.com www.bulldogsecure.com

WW100B-1

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.

**IMPORTANT
READ
THIS FIRST**